


# SERIAL NUMBER LOCATION

You need to know the frame and engine serial numbers to get title documents for your Go-kart. You also need these numbers to help your authorized service center or Baja Motorsports order parts.

The Frame number is located on the left side of driver. The engine number is located on the front of the engine housing, facing the seat.



Frame number



Engine serial number

Write down the serial numbers here for your future reference

Frame No.:

Engine No.: